

梁断面表																	柱断面表									
No. 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100																	No. 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100 100									
G1																	B1									
G2																	B2									
G3																	B3									
G4																	階									
G5																	C1.8									
G6																	C2.7.9									
G6'																	C3.4.5									
[Reinforcement diagrams for beams G1-G6']																	[Reinforcement diagrams for columns B1-B3]									
[Dimensions and notes for beams]																	[Dimensions and notes for columns]									

